

## RESTRICCIONES DE USO - USE RESTRICTIONS

### RH110

- No es posible colocar en cabecero de puerta Massen rasante a pared.
- Para otro modelo de puerta no rasante pared, se requiere al menos 180 mm de cabecero.
- *Impossible to assemble on a Massen door header not flush with wall.*
- *For any other door model not flush with wall, a header height of at least 180 mm is required.*



### SV010, S101, S102

- No es posible colocar en larguero de puerta Massen. Se necesitan al menos 110 mm de ancho.
- *Impossible to assemble on a Massen door upright. An upright width of at least 110 mm is required.*



### EUROCYLINDER STYLE MT42 BLENDE

- Botoneras de superficie de planta: como máximo, 1 llavín por botonera en el alojamiento inferior. No se puede colocar en la botonera de 4 elementos (S010).
- Botoneras de superficie de cabina: hasta 2 llavines (en la fila inferior de la parte de pulsadores de llamada).
- **Importante:** tenga en cuenta que el fondo del llavín sobresale 21 mm en la parte trasera de la botonera de planta y 12 mm en el caso de la botonera de cabina. Por eso, necesitará prever ese espacio para poder alojarlo.
- *Surface mounted LOPs: 1 keyswitch per LOP at the lowest hole. Impossible to be included in plates of 4 elements (S010).*
- *Surface mounted COPs: up to 2 keyswitches (at the lowest row of call pushbuttons).*
- **Important:** keep in mind that the keyswitch protrudes from the rear side of the LOP in 21 mm and in 12 mm of the COP. Therefore, an extra space is required to get it housed.

